

# CRITICAL INSTRUCTIONS

Application: **Audi/Seat/Skoda/VW 1.9TD**

Part Number:  
**5439988002**  
**751851-5003S**  
**751851-5004S**

WHEN FITTING THIS TURBO, IT IS **CRITICAL** THE FOLLOWING INSTRUCTIONS ARE ADHERED TO:

- **Remove air intake pipework before fitting the turbo**

Prior to fitting the new turbocharger remove the air intake and engine breather pipework, situated between the turbocharger and the air filter box.

Check the pipework for debris and/or damage and clean/replace as necessary.

Failure to carry out this operation can lead to the new turbocharger being damaged on start up or at low milage.

Please Note – Our standard warranty does not cover turbocharger failure caused by impact damage, so it is essential to follow the above instruction.

**Any questions regarding the above should be directed to the supplier of this unit before commencing any work**

